



®

The Original

Silicone Vapor Shield®

designed by
allglobe™.ca

The Best Rated Underlayment for Hardwood Floors!

- Silicone Vapor Shield® protects hardwood flooring from sub-floor moisture.
- Meets the NWFAs's guidelines for a vapor retarder – which significantly reduces the risk of cupping.
- Protects the house environment – by not off gassing hazardous V.O.C's.
- Does not contain tar or petroleum based waxes.
- Does not decay after installation – maintains effectiveness as a vapor barrier.
- Allows planks to slide easily during installation – tear resistant.
- The only underlayment that can be used over radiant heat.
- Prop 65 compliant.
- Tested perm rating of 0.712 for nailed down applications.



GREEN 100% RECYCLED

Country of origin: USA Made Paper (Processed in Canada)

Weight per 400 sq. ft. roll: 11.5 lbs.

Square feet per roll: Available in 200 sq.ft., 400 sq.ft., 800 sq.ft., 1000 sq.ft.

MSDS: We do not require a MSDS.

Specs: Silicone Vapor Shield® Paper is made of a high quality, 6-8 mil. bleached wet strength paper with a Silicone Coating on one side that has been baked one or two times.



Installation Instructions

1. Cut the first strip of Silicone Moisture Barrier the full length of the starting wall and position the underlayment shiny side up.
2. Secure the underlayment with staples along the wall only with enough staples to keep the underlayment flat.
3. Position succeeding rows under previous rows with a 4" overlap so that the boards slide easily. No need to tape or staple the succeeding rows.

When installing please refer to NWFA installation guidelines*

Instructions d'installation

1. Couper la première bande de Barrière anti-moisissure en silicone pour toute la longueur du mur de départ et placer la sous-couche côté brillant vers le haut.
2. Fixer la sous-couche avec des agrafes le long du mur uniquement avec un nombre d'agrafes juste assez suffisant pour que la sous-couche soit bien à plat.
3. Positionnez les rangées suivantes sous les précédentes avec un chevauchement de 4 pouces de sorte que les panneaux puissent glisser facilement. Il n'est pas nécessaire d'utiliser un ruban adhésif ou des agrafes pour les rangées qui suivent.

*Pour l'installation, veuillez vous référer aux lignes directrices de la NWFA**

Instrucciones de instalación

1. Cortar la primera tira de Barrera de silicona contra la humedad la longitud total de la pared y colocala en el piso con la capa brillante hacia arriba.
2. Fije la base con grapas a lo largo de la pared usando suficiente grapas para mantener la base plana.
3. Las filas siguientes deben ir puestos a lo largo de la tira anterior, pero que la tira anterior lo cubra a lo largo con 4" de producto. Este permite que al instalar el piso, las tablas de madera se deslizaran con facilidad. No hay necesidad de colocar cinta ni grapas en las filas posteriores.

*Cuando se instala, por favor vaya a guía de instalación NWFA**

*National Wood Flooring Association



www.robertsconsolidated.com

Roberts Consolidated Industries, Inc.
Boca Raton, FL 33487

Made in Canada with recycled
U.S.A. paper • Fabriqué au Canada
avec papier recyclé de É.-U. • Hecho en
Canada con papel reciclado de E.U.A. • S2120-11576

70-198

